



HARKEN[®]
INDUSTRIAL WINCHES 46
IN46.2STA - IN46.2STC - IN46.2STGNA - IN46.2STGNC - IN46.2STGNA-M
User manual

Original Instruction

UIN46.2ST-F 18-03-2025

Introduction	5
Glossary and Symbols.....	5
General Information.....	6
Identification Data and Plates on the Device	6
Safety Information.....	7
General Advice.....	7
Intended Use.....	7
Improper Use	7
Personal Protective Equipment (PPE).....	8
Residual Risks	8
System Description.....	9
<i>Parts Description</i>	9
Outline Winch IN46.2STa - IN46.2STC	10
Outline Winch IN46.2STGNA - IN46.2STGNC - IN46.2STGNA-M	10
Max Working Load	11
Rope Requirements.....	11
Technical Data	11
Winch Installation.....	12
<i>Mounting Surface</i>	12
<i>Winch Entry Angle of Pulling Rope</i>	12
<i>Winch Location</i>	12
<i>Mounting Template</i>	13
<i>Installation Procedure</i>	14
<i>Procedure 1</i>	14
<i>Procedure 2</i>	16
Winch Use	18
Using The Device - Checking The Device Before Use.....	18
Pulling Load.....	19
Winch Maintenance	21
Maintenance	21
<i>Wash</i>	21
<i>Maintenance Schedule</i>	21
<i>Disassembly procedure</i>	21
<i>Exploded View With Maintenance Products IN46.2STA - IN46.2STC</i>	25
<i>Exploded view with maintenance products IN46.2STGNA - IN46.2STGNC</i>	26

<i>Exploded view with maintenance products IN46.2STGNA-M</i>	27
<i>Assembly</i>	28
<i>Exploded view of IN46.2STA - IN46.2STC</i>	29
<i>Part list of IN46.2STA</i>	31
<i>Part list of IN46.2STC</i>	32
<i>Exploded view of IN46.2STGNA - IN46.2STGNC</i>	33
<i>Part list of IN46.2STGNA</i>	34
<i>Part list of IN46.2STGNC</i>	35
<i>Exploded view of IN46.2STGNA-M</i>	36
<i>Part list of IN46.2STGNA-M</i>	37
Handling	38
Storage.....	38
Maintenance Schedule.....	39
Worldwide Limited Warranty	42

GLOSSARY AND SYMBOLS

Intended Use - use of the device according to the information supplied in the instructions for use.

Improper Use - use of the device in a way different from that indicated in the instructions for use.

General User - a user that use the device to pulling loads

Text preceded by the following symbols contains very important information or instructions, especially in regards to safety.

Failure to observe these may lead to:

- danger for operators
- invalidity of the contract warranty
- refusal of the manufacturer to accept responsibility



WARNING!

This denotes the existence of the potential danger, which could cause injury or damage if the information or instructions are not followed






NOTE!

This denotes important information concerning the device

General Information

IDENTIFICATION DATA AND PLATES ON THE DEVICE

Each device is identified by a plate on which the reference data of the device are inscribed indelibly. Always quote these references when contacting the manufacturer or service centres.

HARKEN Italy spa		Industrial Winches 46	
via Marco Biagi, 14 Limido Comasco (CO) 22070 - Italy www.harken.com ☎ (+39) 031 3523511	Winch Model: IN46.2STA - IN46.2STC - IN46.2STGNA - IN46.2STGNC - IN46.2STGNA-M	Serial No. / N. di serie	MADE IN ITALY
 	Max Working Load (MWL): Pulling Load: 750kg (objects) Trazione: 750kg (oggetti)		
Minimum 2 turns clockwise, rope: Minimo 2 giri in senso orario, fune: IN46.2STA-IN46.2STC: 8mm-14mm (5/16" - "9/16") IN46.2STGNA-IN46.2STGNC-IN46.2STGNA-M: 10mm-22mm (3/8"-7/8")			

1		2	
3	4		5
	6		
7	8		

1. Name of manufacturer.
2. Name of product.
3. Manufacturer's identification data.
4. Winch Model.
5. Serial number in format:

S XXXXX
XXXXXXXXXX

last two numbers of the year of manufacture of the device (e.g. 15 = the year 2015).

6. Indicator of the Max Working Load (MWL) of the device for pulling loads.
7. Pictogram instructing you to read the manual before using the device.
8. Safety information of Minimum turns and the diameter of the rope to use:
 - IN46.2STA-IN46.2STC: 8mm-14mm (5/16"-9/16");
 - IN46.2STGNA-IN46.2STGNA: 10mm-22mm (3/8"-7/8");
 - Pictogram showing the direction of rotation of the rope on the winch.

The plate is on the skirt of the device (see figure on right)



GENERAL ADVICE

Use of the Industrial Winches 46 for pulling loads is permitted to a general user in accordance with National Regulations & Working Guidelines/Practices.

Harken® is not responsible for damage caused by the Industrial Winches 46 to people, animals or property in the case of:

- improper use of the Industrial Winches 46
- lack of proper maintenance, as indicated in the Maintenance chapter of this Manual
- unauthorised modifications or changes
- use of spare parts that are not original or specific for the model
- total or partial failure to observe the instructions
- usage contrary to specific national regulations

INTENDED USE

This winch is designed to be used as a manually powered, rope-handling winch for pulling loads.

This product, as supplied by Harken, is considered to be applicable to general pulling operations. Should this product be incorporated into systems for lifting objects and/or persons, it must be CE Certified for its intended application adding the appropriate additional safety devices. Such systems are classified as “machinery for lifting objects and/or persons” and needs to be CE Certified

IN46.2STA - IN46.2STC winches are more suitable for use in marine environments.

IN46.2STGNA - IN46.2STGNC winches are more suitable for heavy duty cycles (not in marine environments).

IN46.2STGNA-M winche is more suitable for heavy duty cycles in marine environments.

IMPROPER USE

The winch must not be used:

- for purposes different from those outlined in “Intended use” chapter, or for purposes not mentioned in this manual or different from those mentioned
- if unauthorised modifications or interventions have been carried out
- in an explosive atmosphere
- after it has fallen from a height of more than 1 meter onto a hard surface. In this case the device must be returned to the manufacturer or to a Harken® authorised repair centre
- with wire rope
- with loads in excess of the Maximum Working Load (MWL) of 750 kg for pulling loads

**WARNING!**

Subjecting the winch to loads above the maximum working load can cause the winch to fail or pull off the mounting surface suddenly, possibly resulting in severe injury or death.

Safety Information

PERSONAL PROTECTIVE EQUIPMENT (PPE)

It is necessary use gloves when operating the device.



RESIDUAL RISKS

You must pay attention to the following residual risks present when using Industrial Winches 46:



WARNING! Rotating Parts Trapping Risk

Always wear clothing and protective gloves that are form fitting. Avoid loose gloves or clothing and always follow the instructions in the manual.


SYSTEM DESCRIPTION

Parts Description




Pos.	Description
1	Socket Handle
2	Upper Jaw
3	Lower Jaw
4	Peeler
5	Stripper Arm
6	Drum
7	Skirt

OUTLINE WINCH IN46.2STA - IN46.2STC



OUTLINE WINCH IN46.2STGNA - IN46.2STGNC - IN46.2STGNA-M



Note: all dimensions are in mm.

MAX WORKING LOAD

The Max Working Load (MWL) of the Industrial Winches 46 is:

- 750 kg (1653 lb) for pulling loads



WARNING!

Do not apply a load greater than the Max Working Load (MWL) to the Winch.

ROPE REQUIREMENTS



WARNING!

Use only ropes with a diameter listed in this manual for each model of Winch.



WARNING!

Use only ropes in good condition.



WARNING!

For correct maintenance of ropes consult the rope Usage Manual.



WARNING!

Do not use with wire rope.

TECHNICAL DATA

Rope	IN46.2STA-IN46.2STC: 8mm-14mm (5/16" - "9/16") for pulling loads
	IN46.2STGNA-IN46.2STGNC-IN46.2STGNA-M: 10mm-22mm (3/8"-7/8") for pulling loads
Max Working Load (MWL)	750 kg (1653 lb) for pulling loads
Gear Ratio	IN46.2STA-IN46.2STC: 2,30:1 - 1 st speed / 9,17:1 - 2 nd speed
	IN46.2STGNA-IN46.2STGNC-IN46.2STGNA-M: 2,30:1 - 1 st speed / 9,51:1 - 2 nd speed
Power Ratio	IN46.2STA-IN46.2STC: 11,70:1 - 1 st speed / 46,50:1 - 2 nd speed
	IN46.2STGNA-IN46.2STGNC-IN46.2STGNA-M: 11,70:1 - 1 st speed / 48,30:1 - 2 nd speed
Winch Weight	IN46.2STA: 5.2 kg (11.46 lb)
	IN46.2STC: 7.8 kg (17.19 lb)
	IN46.2STGNA: 6,2 kg (13,67 lb)
	IN46.2STGNC: 9,12 kg (20,10 lb)
	IN46.2STGNA-M: 5,8 kg (12,79 lb)
Winch Handle suggested length (not included)	254 mm (10")
Winch Dimensions	IN46.2STA-IN46.2STC: 201 x Ø184 mm (7,92" x Ø,24")
	IN46.2STGNA-IN46.2STGNC-IN46.2STGNA-M: 226 x Ø184 mm (8,89" x Ø,24")
Recommended working temperature range	-10°C +50°C




Winch Installation

Mounting Surface

Winch must be installed on a flat surface, reinforced if necessary, to withstand a load equal to 3000 kg.

Winch Entry Angle of Pulling Rope

Winch entry angle must be 8° with a tolerance of $\pm 2^\circ$ to avoid rope overrides.



WARNING!

Verify entry angle of rope. It must be 8° with tolerance of $\pm 2^\circ$, to avoid rope overrides and damaging winch or making winch inoperable, leading to loss of control, possibly resulting in severe injury or death.

Mount winch so drive gear is positioned where rope enters winch drum.

Note: ▲ on winch skirt identifies location of drive gear.



WARNING!

Mount winch so that drive gear is positioned where rope enters winch drum. Incorrect positioning of drive gear can weaken winch leading to failure, possibly resulting in severe injury or death.

Winch Location

Winch must be installed in a position to allow sufficient working space around unit, so not to impede operation of handles.

Winch must be installed in a position to ensure visibility of the load trajectory by operator at all times.




WARNING!

Incorrect installation of winch may cause severe injury or death. Consult equipment supplier if in doubt about correct position of winch.

Harken® accepts no responsibility for defective installation or reassembly of its winches. If you have questions or concerns, Harken® Tech Service is at your disposal at techservice@harken.it.

Mounting Template



Note: all dimensions are in mm - DRAWING NOT IN SCALE.

**NOTE!**

Drilling template is available on Harken® website, www.harken.com. Download, print and compare template to winch to verify that size of template and hole position/sizes are correct.

**NOTE!**

When downloading winch templates make sure you have correct size paper and that printer will output at 100%. Before drilling holes verify that template is correct in every detail. Harken cannot be responsible for incorrectly drilled holes because of a faulty template.

**NOTE!**

1/4" Hex Head bolts do not fit in the holes and cannot be used to mount winch

Winch Installation

Installation Procedure

Harken® does not supply bolts to install winch since lengths may vary depending on mounting surface.

It is installer's responsibility to choose correct bolts, taking into account loads they will have to withstand.

Harken® assumes no responsibility to incorrect installation of winch and plate adapter or for use of incorrect mounting bolts.



WARNING!

Failure to use correct number and type of mounting fasteners or failure to ensure correct mounting surface strength can result in winch pulling off suddenly and unexpectedly during high loads, possibly resulting in severe injury or death.



WARNING!

Incorrect installation of winch plate may cause severe injury or death. Consult equipment supplier if in doubt about correct position of winch plate.

The Industrial Winches 46 can be installed following one of the two procedures below (**Procedure 1** or **Procedure 2**):

Procedure 1

To install the Winch you must remove the drum and use bolts as described ahead.

Tool needed: one medium flat-bladed screwdriver , one number five hex key. 

To identify the various parts, refer to the exploded view at the end of this Manual.

Torque to apply when assembling is indicate on this manual with 

Only for IN46.2STA-IN46.2STC



1. Unscrew the central screw (2Nm/18 in-lb).

Only for IN46.2STGNA-IN46.2STGNC- IN46.2STGNA-M



1a. Unscrew the central screw (12Nm/106 in-lb).



2. Slide off the assy socket and the cover.



3. Unscrew the three screws (4Nm/35 in-lb).



4. Remove the self-tailing arm by rotating and lifting it.



5. Lift the drum.

Install the Winch on the position you have chosen, keeping in mind the limits described on page 12-13 and using socket head (SH) bolts.

Winch Installation

Procedure 2

To install, you must remove the winch skirt and use hexagonal headed bolts.

Tools needed: one medium flat-bladed screwdriver. 

To identify the various parts, refer to the exploded view at the end of this Manual.



1. Remove the skirt with the help of the screwdriver placed as shown by the symbol 



2. Take off the skirt



3. Position the n°5 M8 hexagonal headed bolts in their holes





4. Reposition the skirt in its housing



5. Press down the skirt to position it correctly



NOTE!

Make sure the skirt is correctly clipped on to the base of the winch.

Install the Winch on the mounting surface and in the position you have chosen, keeping in mind the limits described on page 12-13 and using hexagonal headed bolts (HH).

Carry out **Procedure 1** or **Procedure 2**, then install the Winch on the chosen position and continue as follows:

- A.** Position the base of the Winch on the chosen position and mark the holes or use the drilling cut-out template (page 13).
- B.** Remove the Winch and drill the five 8.2 mm diameter holes. If drilling and tapping consult industry standards for drill/tap size.
- C.** Bolt the base of the Winch using five M8 bolts, washers, and nuts (not supplied by Harken®) as described at **Procedure 1** or **Procedure 2**.



WARNING!

To install the Winch, use only bolts in A4 stainless steel (DIN 267 part11). Bolts made of other materials may not have sufficient strength or may corrode which can result in winch pulling off the mounting surface suddenly and unexpectedly during high loads causing severe injury or death..



NOTE!

To obtain correct Maximum Working Load (MWL) all five bolts, nuts, and washers must be securely tightened. To mount winches do not use countersunk bolts.

- D.** Reassemble the Winch following the steps in **Procedure 1** or **Procedure 2** in the reverse order.



WARNING!

Failure to use correct number and length of mounting fasteners and/or failure to tighten them correctly can result in winch pulling off suddenly and unexpectedly during high loads which may cause load to drop, possibly resulting in severe injury or death.

USING THE DEVICE - CHECKING THE DEVICE BEFORE USE

Check the correct operation of the Winch by rotating the drum by hand in one direction and check the rotation lock in the opposite direction.

Acting on handles, verify the correct rotation of the Winch drum in first speed and reversing the rotation direction of the handle, in second speed.

**WARNING!**

Before each use, visually inspect the winch for signs of wear, damage or failure. If such signs are present, do not use the device. If the worn or defective parts are not immediately replaced, the manufacturer will assume no responsibility for resulting damage or accidents.

**WARNING!**

Before each use inspect winch and jaws for degradation, cracks, or wear that may affect locking strength and operation. Check pulling rope to make sure that it is free from wear. If in doubt, replace with a suitably strong rope.

**WARNING!**

Before each use check winch base securely fastened to plate. Failure to use correct number and length of mounting fasteners and/or failure to tighten them correctly can result in winch pulling off suddenly and unexpectedly during high loads which may cause load to drop, possibly resulting in severe injury or death.

**WARNING!**

Before each use check the winch drum cannot be turned by hand counter-clockwise.

PULLING LOAD



WARNING!

Keep fingers, loose clothing, hair etc away from winch. Area around winch handle should be kept clear of people and objects at all times.

To pull loads, proceed as follows:

1. Starting from the base, wind the rope on the drum of the Winch in a clockwise direction.
2. Ensure that the rope does not override (overlap) on the Winch.



WARNING!

Take at least two turns of the rope around the winch drum, and if it slips under load increase the number of turns to a maximum of four, taking care not to overlap the rope.



NOTE!


The number of turns needed round the winch drum depends on the load and the condition of the rope.




WARNING!

Never allow rope to (override) overlap on winch drum. This can cause rope to jam and can prevent load from being pulled.

3. Pull rope through to take up any slack, then pass the rope on the stripper arm by winding rope clock-wise and pulling tight to engage.
4. Fit the rope into the jaws.



INCORRECT



CORRECT




WARNING!

Ensure correct placement of rope on the stripper arm and into the spring loaded jaws. Failure to secure the rope in the jaws may cause rope slippage.

5. Start by turning both handles to lift the load clockwise. The gears automatically engage according to the direction of rotation.

1st gear: turn the handle clockwise (looking at the Winch from above).

2nd gear: turn the handle counterclockwise (looking at the Winch from above).



7. When the handle becomes difficult to rotate in 1st gear, reverse the direction to engage 2nd. A higher power ratio makes a heavier load easier to lift with the same effort.



NOTE!

The maximum input speed of the Industrial Winches 46 is 60 rpm.

MAINTENANCE**NOTE!**

A formal inspection of the winch must be performed at least annually by trained personell. The inspection should be recorded in an inspection and maintenance log (see Maintenance schedule at the end of this manual).

Wash

Wash the Winch frequently with fresh water.

Do not allow cleaning products or other caustic solutions to come into contact with Winch, especially anodized, chrome-plated, or plastic parts. Do not use solvents, polishes, or abrasive pastes on logos or winch stickers.

Maintenance Schedule

Winch must be completely overhauled, cleaned, and lubricated at least every 12 months. Maintenance of Winches must be carried out exclusively by trained personnel. Harsh environment and/or heavy use may require more frequent maintenance.

**NOTE!**

Do not replace or modify Winch with a part that was not designed for it.

**WARNING!**



Periodic maintenance must be carried out regularly. Lack of adequate maintenance shortens the life of the Winch, can cause serious injury and also invalidate the winch warranty.

**NOTE!**

Maintenance of winches must be carried out exclusively by trained personnel.

Disassembly procedure

Tool needed:

- One medium flat-bladed screwdriver 
- A number five hex key 
- Rags

To identify the various parts refer to the exploded view at the end of this Manual.

Torque to be applied in assembly phase 

Winch Maintenance


Carry out **Procedure 1** as shown at page 16 and then do the following steps:



1. Completely unscrew the three screws and remove the stripper arm support



- 1a. Unscrew the three screws (4 Nm/35 in-lb) and remove the stripper arm support and socket spacer




2. Slide out the central shaft



3. Unscrew the 5 hex screws (20 Nm/177 in-lb)



4. Remove the assy housing
Important: washer may remain inside the drum support!



5. Remove the gear



6. Remove the washer



7. Remove the gear and remove the pawls carrier.



8. Remove the gear



9. Remove the pinion. To facilitate the operation press the spring against the pawl with a blade



10. Slide off gear

Winch Maintenance



11. Remove washer

If it is necessary to replace any jaws of the winch, proceed as follows:



I. Unscrew the 4 screws ($\approx 4\text{Nm}/35\text{ in-lb}$)



II. Remove the jaws. (remove four screws and spacer, only for winch model IN46.2STGNA and IN46.2STGNA-M)

Once the winch is completely disassembled, clean the parts with a degreasing that does not leave residues, proper to clean metal components; rinse plastic parts in fresh water. Once you have done this, dry the parts with cloths that do not leave residue.

Inspect gears, bearings, pins and pawls for any signs of wear or corrosion.

Carefully check the teeth of gears and ring gears to make sure there are no traces of wear.

Check the roller bearings and check there are no breaks in the bearing cages.

Replace worn or damaged components.


Carry out maintenance on components using the products listed below.

For more information on which products to use where, refer to the exploded diagram below.

Use a brush to lightly lubricate all gears, gear pins, teeth and all moving parts with grease.

Lightly lubricate the pawls and springs with oil. **Do not use grease on the pawls!**

Exploded View With Maintenance Products IN46.2STA - IN46.2STC




Apply Harken® grease where indicated above
 Apply Harken® grease: 1. on assy socket screw - 2. on drum gear

Winch Maintenance


Exploded view with maintenance products IN46.2STGNA - IN46.2STGNC

- A** Anti-seize
- G** Harken® Grease
- O** Harken® Pawl Oil



Apply Harken® grease where indicated above
Apply Harken® grease: 2. on drum gear

Exploded view with maintenance products IN46.2STGNA-M



Winch Maintenance



NOTE!

On every gear and every component that must be greased, apply Harken® grease with a brush in a proper quantity as shown below:



NOTE!

Harken® grease to apply on all teeth: do not use excessive quantity of product to void wastes. If in contact with the pawls, an excess of grease can compromise the safety of the winch.

Assembly

Make sure that the holes and drainage channels in the base of the winch are not obstructed.

Assemble the winch in the reverse order of the sequence in the section on disassembly.


To tighten bolts, use the torque indicated in the disassembly procedure.



When positioning the stripper arm, align the peeler with it.



If the jaws have been disassembled, insert peeler between the two jaws, taking care that the letters TOP on the peeler are facing upwards.



To assemble the pawls:


Correctly position the spring in its housing as shown at left.


Hold the spring closed and slide the pawl into its housing.

Once in position, check that the pawls can be easily opened and closed with a finger.

In case of doubt concerning the assembly procedure contact Harken® Tech Service: techservice@harken.it

Exploded view of IN46.2STA - IN46.2STC





Part list of IN46.2STA**Winch IN46.2STA**

A= drum in anodised aluminium

Pos.	Q.ty	Code	Description	Pos.	Q.ty	Code	Description
1	1	A94132100	Assy Base Winch 46	19	1	S413390080	Spacer
	1	S413350080	Base W46	20	1	A94161400	Assy Central Shaft Winch 46
	1	S4152300A7	Roller Ø6x19		1	S413880002	Central shaft W46 ST
	1	S414890080	Bushing Ø22xØ25x9.5				Washer Ø17.2xØ32x1.5
	1	S413330085	Bushing Ø9xØ11x7	21			Winch Serial Number Sticker
	1	S413330085	Bushing Ø12xØ14x11	22	1	S4129400A0	Stripper arm support
2	1	A97306100	Assy Skirt Industrial Winches 46	23	1	S412720053	Drum W46
			Skirt W46	24	1	S281690097	Red line
			Product Sticker Industrial Winches 46	25	1	A94127300	Assy Jaws winch 46
3	1	S413020004	Gear Z12				Lower Jaw W46
4	1	S413300004	Pin Ø12x60				Upper Jaw W46
5	1	S278170002	Washer Ø12.5xØ48x1.5		1	S414280080	Peeler W46 - 50
6	1	S413260004	Gear Z27		4	S385970001	SPRING
7	1	S414260004	Pawls Carrier Ø8xN2	26	4	M0601803	Screw UNI EN ISO 1207- M6x35 - A4
8	6		Pawl Ø8 (*)	27	1	S413380019	Stripper Arm W46
9	6		Pawl Spring Ø8 (*)	28	3	M6007103	Screw M6x50 UNI6107
10	1	S412830041	Gear Z23	29	1	S4127000A5	Cover 2 speed W46
11	1	S413250041	Pinion Z13	30	1	A94136400	Assy Socket W20-80
12	2	M6017694	Bushing PSM-1214-20				Socket Handle W20/80
13	1	S413120002	Washer Ø22.5xØ45x1		1	S415130085	Washer Ø7.7xØ25x5.8
14	1	S413070004	Pin Ø9xØ12x32.5		1	M0614303	Screw M8x20 UNI 6109
15	1	A94133400	Assy Gear Z12				
			Gear Z12				
	2	S414900080	Bushing Ø12xØ14x8				
16	1	A94132200	Assy Housing Winch 46				
			Housing Winch 46				
	1	S414900080	Bushing Ø12xØ14x8				
	1	S413330085	Bushing Ø12xØ14x11				
	1	S4133200B3	Bushing for support				
17	5	M0606303	Screw M8x25 UNI 5931				
18	2	A74133700	Bearing Ø75xØ87x26				

(*) Available with service kit BK4512; see website www.harken.com

Winch Maintenance

Part list of IN46.2STC

Winch IN46.2STC


C=drum in chrome bronze

Pos.	Q.ty	Code	Description	Pos.	Q.ty	Code	Description
1	1	A94132100	Assy Base Winch 46	19	1	S413390080	Spacer
	1	S413350080	Base W46	20	1	A94161400	Assy Central Shaft Winch 46
	1	S4152300A7	Roller Ø6x19		1	S413880002	Central shaft W46 ST
	1	S414890080	Bushing Ø22xØ25x9.5				Washer Ø17.2xØ32x1.5
	1	S413330085	Bushing Ø9xØ11x7	21			Winch Serial Number Sticker
	1	S413330085	Bushing Ø12xØ14x11	22	1	S4129400A0	Stripper arm support
2	1	A97306100	Assy Skirt Industrial Winches 46	23	1	S413240043	Drum W46 C
			Skirt W46	24	1	S281690097	Red line
			Product Sticker Industrial Winches 46	25	1	A94127300	Assy Jaws winch 46
3	1	S413020004	Gear Z12				Lower Jaw W46
4	1	S413300004	Pin Ø12x60				Upper Jaw W46
5	1	S278170002	Washer Ø12.5xØ48x1.5		1	S414280080	Peeler W46 - 50
6	1	S413260004	Gear Z27		4	S385970001	SPRING
7	1	S414260004	Pawls Carrier Ø8xN2	26	4	M0601803	Screw UNI EN ISO 1207 - M6x35 - A4
8	6		Pawl Ø8 (*)	27	1	S413380019	Stripper Arm W46
9	6		Pawl Spring Ø8 (*)	28	3	M6007103	Screw M6x50 UNI6107
10	1	S412830041	Gear Z23	29	1	S4127000A5	Cover 2 speed W46
11	1	S413250041	Pinion Z13	30	1	A94136400	Assy Socket W20-80
12	2	M6017694	Bushing PSM-1214-20				Socket Handle W20/80
13	1	S413120002	Washer Ø22.5xØ45x1		1	S415130085	Washer Ø7.7xØ25x5.8
14	1	S413070004	Pin Ø9xØ12x32.5		1	M0614303	Screw M8x20 UNI 6109
15	1	A94133400	Assy Gear Z12				
	2	S414900080	Gear Z12				
			Bushing Ø12xØ14x8				
16	1	A94132200	Assy Housing Winch 46				
	1	S414900080	Housing Winch 46				
	1	S413330085	Bushing Ø12xØ14x8				
	1	S4133200B3	Bushing Ø12xØ14x11				
			Bushing for support				
17	5	M0606303	Screw M8x25 UNI 5931				
18	2	A74133700	Bearing Ø75xØ87x26				

(*) Available with service kit BK4512; see website www.harken.com



Exploded view of IN46.2STGNA - IN46.2STGNC



(*) Installed only on Winch IN46.2STGNA.

Winch Maintenance

Part list of IN46.2STGNA

Winch IN46.2STGNA

A= drum in anodised aluminium

Pos.	Q.ty	Code	Description	Pos.	Q.ty	Code	Description
1	1	A97412300	Assy Base Winch IN46.2	16	5	M0606303	Screw M8x25 UNI 5931
	1	S413350080	Base IN46.2	17	2	A74133700	Bearing Ø75xØ87x26
	1	S737270004	Roller Ø6x19	18	1	S413390080	Spacer
	1	S414890080	Bushing Ø22xØ25x8.5	19	1	S418760063	Winch Serial Number Sticker
	1	S413330085	Bushing Ø9xØ11x7	20	1	A97306000	Drum assembly 46 ST GNP
	1	S413330085	Bushing Ø12xØ14x11		1	A96595400	Assy Jaws Winch 46 Arborist
	1	M6034408	Bearing 25x37x7				Lower Jaw Assembly W46 Arborist
2	1	A97306100	Assy Skirt Industrial Winches 46				Upper Jaw W46
			Skirt W46		1	S659590080	Peeler W46 Arborist
			Product Sticker Industrial Winches 46		4	S385970001	Spring
3	1	S413020004	Gear Z12		1	S412720053	Drum W46
4	1	S741260008	Pin Ø12x60		4	M0601803	Screw M6x35 UNI EN ISO 1207:1996
5	1	S278170002	Washer Ø12.5xØ48x1.5		4	M0601703	Screw M6x25 Uni 5931
6	1	S740110004	Gear Z28		1	S281690097	Red line
7	1	S414260004	Pawls Carrier Ø8xN2		1	S730320052	Spacer Drum Winch 46STGNA
8	6		Pawl Ø8 (*)	21	1	S6765700A5	Cover 2 speed W46 GNP
9	6		Pawl Spring Ø8 (*)	22	1	A97413500	Assy Socket IN46.2
10	1	S412830041	Gear Z23				Socket Handle W20/80
11	1	S741250041	Pinion Z13		1	S741360003	Washer for Socket IN46.2
12	1	S413120002	Washer Ø22.5xØ45x1		1	S415360003	Screw M6x16 UNI EN ISO 1207:2003
13	1	S413070004	Pin Ø9xØ12x32.5				precote coating
14	1	A94133400	Assy Gear Z12		1	M6072919	Lock Washer ø6
			Gear Z12	23	1	S757770002	Central Shaft
	2	S414900080	Bushing Ø12xØ14x8	24	1	S413380019	Stripper Arm W46
15	1	A97412400	Assy Housing Winch IN46.2	25	3	M0635103	Screw M6x16 UNI5931
			Housing Winch 46	26	1	A77575800	Stripper Arm Support GNP
	1	S414900080	Bushing Ø12xØ14x8				Support GNP
	1	S413330085	Bushing Ø12xØ14x11		1	M7576202	Ball Bearing
	1	S7412400B3	Bushing for support IN46.2		3	M0603703	Screw M6x12 UNI5931
	1	M6034408	Bearing 25x37x7	27	3	M6034617	Roller bearing Nadella DL 12 12
	1	S737270004	Bushing Ø22xØ25x8.5	28	1	S757760002	Ball Bearing

(*) Available with service kit BK4512; see website www.harken.com




Part list of IN46.2STGNCWinch IN46.2STGNC

C=drum in chrome bronze

Pos.	Q.ty	Code	Description	Pos.	Q.ty	Code	Description
1	1	A97412300	Assy Base Winch IN46.2 <i>Base IN46.2</i>	16	5	M0606303	Screw M8x25 UNI 5931
	1	S413350080	<i>Roller Ø6x19</i>	17	2	A74133700	Bearing Ø75xØ87x26
	1	S737270004	<i>Bushing Ø22xØ25x8.5</i>	18	1	S413390080	Spacer
	1	S414890080	<i>Bushing Ø9xØ11x7</i>	19	1	S418760063	Winch Serial Number Sticker
	1	S413330085	<i>Bushing Ø12xØ14x11</i>	20	1	A96596100	Drum assembly 46 ST GNP
	1	M6034408	<i>Bearing 25x37x7</i>		1	A96595400	<i>Assy Jaws Winch 46 Arborist</i>
2	1	A97306100	Assy Skirt Industrial Winches 46 <i>Skirt W46</i>		1	S659590080	<i>Lower Jaw Assembly W46 Arborist</i>
			<i>Product Sticker Industrial Winches 46</i>		4	S385970001	<i>Upper Jaw W46</i>
3	1	S413020004	Gear Z12		1	S659610043	<i>Peeler W46 Arborist</i>
4	1	S741260008	Pin Ø12x60		4	M0601803	<i>Spring</i>
5	1	S278170002	Washer Ø12.5xØ48x1.5		1	S281690097	<i>Drum W46 ST GNP</i>
6	1	S740110004	Gear Z28		1	S6765700A5	<i>Screw M6x35 UNI EN ISO 1207:1996</i>
7	1	S414260004	Pawls Carrier Ø8xN2		1		<i>Red line</i>
8	6		Pawl Ø8 (*)	21	1		Cover 2 speed W46 GNP
9	6		Pawl Spring Ø8 (*)	22	1	A97413500	Assy Socket IN46.2
10	1	S412830041	Gear Z23		1	S741360003	<i>Socket Handle W20/80</i>
11	1	S741250041	Pinion Z13		1	S415360003	<i>Washer for Socket IN46.2</i>
12	1	S413120002	Washer Ø22.5xØ45x1		1	M6072919	<i>Screw M6x16 UNI EN ISO 1207:2003</i>
13	1	S413070004	Pin Ø9xØ12x32.5		1		<i>precote coating</i>
14	1	A94133400	Assy Gear Z12		1		<i>Lock Washer ø6</i>
	2	S414900080	<i>Gear Z12</i>	23	1	S757770002	Central Shaft
			<i>Bushing Ø12xØ14x8</i>	24	1	S413380019	Stripper Arm W46
15	1	A97412400	Assy Housing Winch IN46.2	25	3	M0635103	Screw M6x16 UNI5931
	1	S414900080	<i>Housing Winch 46</i>	26	1	A77575800	Stripper Arm Support GNP
	1	S413330085	<i>Bushing Ø12xØ14x8</i>		1	M7576202	<i>Support GNP</i>
	1	S7412400B3	<i>Bushing Ø12xØ14x11</i>		3	M0603703	<i>Ball Bearing</i>
	1	M6034408	<i>Bushing for support IN46.2</i>		3	M6034617	<i>Screw M6x12 UNI5931</i>
	1	S737270004	<i>Bearing 25x37x7</i>	27	3		Roller bearing Nadella DL 12 12
	1		<i>Bushing Ø22xØ25x8.5</i>	28	1	S757760002	Ball Bearing

(*) Available with service kit BK4512; see website www.harken.com

Exploded view of IN46.2STGNA-M



Part list of IN46.2STGNA-M

Winch IN46.2STGNA-M

A= drum in anodised aluminium

Pos.	Q.ty	Code	Description	Pos.	Q.ty	Code	Description
1	1	A94132100	Assy Base Winch IN46.2 Base IN46.2	18	2	A74133700	Bearing Ø75xØ87x26
	1	S413350080	Roller Ø6x19	19	1	S413390080	Spacer
	1	S4152300A7	Bushing Ø22xØ25x8.5	20	1	S418760063	Winch Serial Number Sticker
	1	S414890080	Bushing Ø9xØ11x7	21	1	A96595400	Assy Jaws Winch 46 Arborist Lower Jaw Assembly W46 Arborist Upper Jaw W46
	1	S413330085	Bushing Ø12xØ14x11				
2	1	A97306100	Assy Skirt Industrial Winches 46 Skirt W46 Product Sticker Industrial Winches 46	22	1	S412720053	Drum 46 ST
3	1	S413020004	Gear Z12	23	4	M0601803	Screw UNI EN ISO 1207 M6x35 A4
4	1	S413300004	Pin Ø12x60	24	1	S412720053	Red Line
5	1	S278170002	Washer Ø12.5xØ48x1.5	25	1	S6765700A5	Cover 2 speed W46 GNP
6	1	S413260004	Gear Z27	26	1	A94136400	Assy Socket IN46.2 Socket Handle W20/80
7	1	S414260004	Pawls Carrier Ø8xN2				
8	6		Pawl Ø8 (*)	1	M0614303	Screw M8x20 UNI 6109	
9	6		Pawl Spring Ø8 (*)	27	1	A96595600	Central Shaft
10	1	S412830041	Gear Z23	28	1	S413380019	Stripper Arm W46
11	1	S413250041	Pinion Z13	29	3	M0635103	Screw M6x16 UNI5931
12	2	M6017694	Bushing PSM-1214-20	30	1	S659590080	Peeler W46 Arborist
13	1	S413120002	Washer Ø22.5xØ45x1	31	1	A76765500	Stripper Arm Support GNP Support GNP
14	1	S413070004	Pin ø9-ø12x32.5				
15	1	A94133400	Assy Gear Z12 Gear Z12	3	M0603703	Screw M6x12 UNI5931	
	2	S414900080	Bushing Ø12xØ14x8	32	1	S730320052	Spacer Drum Winch 46STGNA
16	1	A94132200	Assy Housing Winch IN46.2 Housing Winch 46	33	4	M0601703	Screw M6x25 UNI 5931
	1	S414900080	Bushing Ø12xØ14x8				
	1	S413330085	Bushing Ø12xØ14x11				
	1	S4132200B3	Bushing for support				
17	5	M0606303	Screw M8x25 UNI 5931				

(*) Available with service kit BK4512; see website www.harken.com

Winch Maintenance

HANDLING

Protect against extreme temperatures: less than -10°C or more than $+50^{\circ}\text{C}$

Extreme heat may distort composite parts.

Extreme cold can cause the material to become brittle and cause the lubrication to congeal.

STORAGE

Store in clean/dry place

Avoid impact which could damage jaws and skirt; ensure good packaging when shipping.

MAINTENANCE SCHEDULE

Owner name

Product name and Model

Serial Number

Year of manufacture

Date of purchase

Date of first use

Maintenance interval Annual

HARKEN®

Manufacturer

Harken Italy S.p.A.

Via Marco Biagi 14, 22070 Limido Comasco (CO), Italy

Tel 031.3523511; Fax 031.3520031

Web: www.harken.it

Email: info@harken.it

Worldwide Limited Warranty

Refer to the Harken World Limited Warranty on the website at:

<http://www.harken.com/>

The product warranty is accepted only if it has been maintained as specified in this Manual by Harken authorized personnel and is accompanied by Maintenance Schedule properly compiled